



CM1-Globe Quick Guide



Key Light:


Settings OK Back	Settings 1 Phone settings 2 Security setti... OK Back	Phone settings 4 Pref.input m... 5 Key Light OK Back
Key Light 1 enable or disa... Activate Options Back	Key Light 2 Start 13:00 Save Back	Key Light 3 End 08:00 Save Back
Alarm: Organizer 4 Calendar 5 Alarm OK Back	Alarm 00:00 AM 00:00 AM Edit Back	Edit 1 Status On Options Back

First Time POWER ON Remove SIM Card



Use a paper-pin to switch it on. Please switch it off if you will not use the phone for a long period

Insert SIM Card



Notice: This phone supports 1.8V and 3V SIM cards. For Micro SMI and Nano SIM card Please combine with the SIM Adapter of CARD before use.

Warnings: Please turn off the phone before inserting/withdrawing SIM card, Otherwise the SIM card stored data maybe corrupted.

Shortcut Key:

1. Up: Message	1	Unlock:	Press the Left soft key first ① then press the # to unlock ②
2. Down: Calculator	2	Change Language:	If you would like to change into English version, please press *#0044#
3. Left: Calendar	3		
4. Right: Alarm	4		

Edit 2 Time 08:00 Save Back	Edit 5 Alarm tone Ring 1 Options Back	Alarm tone Ring 9 Select from file OK Back
--------------------------------------	------------------------------------------------	-----------------------------------------------------

Vibration:

Profiles OK Back	Profiles General Silent Options Back	Options 1 Activate 2 Customize Select Back
General 1 Alert type Ring only Options Back	Options 1 Change 2 Save Select Back	Alert type Ring only Vib. only OK Back

Customize Ring Tone:

Profiles OK Back	Options 1 Activate 2 Customize Select Back	General SIM Ringtone Ring 2 Options Back
Options 1 Change 2 Save Select Back	SIM Ringtone Ring9 Select from file OK Back	File manager CM1 Options Back
File manager My Music Received Options Back	File manager Going home Remember Options Back	Options 1 Change 2 Save Select Back

Speed Dial:

SingTel 2016/10/01 Menu Names	Local BT Add new contact Options ABC Back	Options 1 Select 2 Phonebook setti Select Back
Phonebook settings 1 Preferred sto... 2 Speed dial OK Back	Speed dial 1 Status 2 Set number OK Back	Status On Off OK Back

CM1 tracker:

CM1 tracker OK Back	Location Service 1 Service (OFF) 2 Audit Number OK Back	Service ON/OFF 1 enable or disable Activate Options Back
Audit Number 1 Request&update 2 Request Only Edit Back	Location Service 3 Report Freq 4 Message info OK Back	CM1 tracker 1 Report Freq Every 15 min Options Back

Time and date:

Settings OK Back	Settings 1 Phone settings 2 Security setti... OK Back	Phone settings 1 Time and date 2 Auto power o... OK Back
Time and date 1 Set home city 2 Set time/date OK Back	Set time/date 1 HH:MM 08:15 Save Back	Set time/date 2 YYYY/MM/DD 2016/10/01 Save Back

Audio player:

*Press the Up/Down key to adjust the volume.
*Press the Left/Right key to select the music.

Audio player OK Back	00:00:00 1/20 List	00:04:16 5	Playlist Going home I've Never Be... Options Back
Options 1 Play 2 Details Select Back	Options 1 Refresh list 2 Refresh list Select Back	Options 3 Refresh list 4 Settings Select Back	Options 1 List auto gen. On Options Back
Options 3 Refresh list 4 Settings Select Back	Player settings 1 List auto gen. On Options Back	Options 2 Details 3 Refresh list Select Back	

Sound recorder:

Sound recorder OK Back	Sound recorder 00:00:00 Options Record	Options 1 New record 2 List OK Back
---------------------------	----------------------------------------------	----------------------------------------------

Schedule Power On/Off:

Settings OK Back	Settings 1 Phone settings 2 Security setti... OK Back	Phone settings 1 Time and date 2 Auto power o... OK Back
Auto power on/off 1 Auto power on 2 Auto power off OK Back	Auto power on 1 07:00 2 00:00 OK Back	Edit 1 Status Enable Options Back

FM Radio:

*Press the Up/Down key to adjust the volume.
*Press the Left/Right key to select the FM channel.

FM radio OK Back	FM radio 98.7 15:35 Options On	Options 1 Channel list 2 Manual input Select Back
Settings 1 Background play On Options Back	Options 5 Record 6 File list Select Back	FM radio 98.7 15:35 Pause Off